

AC Sheet Technical Specifications




UAL Industries Ltd. understands and recognizes the needs of various sectors and delivers smart and sustainable solutions for all its customers. All technical specifications are strictly complied with, resulting in the very best product for the customer.

Standard Length (in metres)	1.50	1.75	◀ + 5mm -10mm	Maximum Overhang Unsupported	300mm
	2.00	2.25		Running metres Per ton(Approx)	76 Metres
	2.50	2.75			
	3.00				
Thickness	6 mm		◀ + Free -0.5mm	Actual area covered (allowing end lap and side lap)	
Pitch	146mm		◀ +6mm -2mm	3.00 Metre long sheet	2.88 Sq.M
				1.50 Metre long sheet	1.36 Sq.M
Depth	48mm		◀ +3mm -5mm	Covering efficiency (allowing end lap and side lap)	
Overall width	1050mm		◀ +10mm -5mm	3.00 Metre long sheet	91%
				1.50 Metre long sheet	87%
Laid width	1010		◀ +10mm -5mm	Approx. weight per running Metre in sheet	13.08 Kgs
Minimum end lap At purlins (for slopes not less than 18 degrees and above)				Approx. weight per 10 Sq. Mts. covered	
				3.00 Metre long sheet	136kgs
				1.50 Metre long sheet	144kgs
Maximum Purlin Spacing				Thermal Transmittance: 'U' value	7.95 w/m deg C.
Maximum rail spacing for vertical cladding				Colour	Natural Grey

AC Sheet Installation Procedure

During the installation of AC sheets, a proper procedure ensures accuracy and goes a long way in making the roof long lasting and strong.

1. Do not stack more than 150 sheets, one over the other. If possible, do not expose to sunlight
2. To lift, hold the sheets only in the places marked 'L'
3. Improper storage of sheets may result in damage of the sheets. The damage will be noticed only after installation
4. Always store sheets on three even level supports. Sheets of varying length should be stacked separately.
5. Always carry the sheets lengthwise, not width wise. If sheets have to be stored for long, keep them indoors.
6. The distance between two purlins should not be more than 1.40 meters for roofing and 1.70 meters for side cladding. Clamp with a purlin at the end of each sheet
7. Do not make holes in the sheet by punching, always drill holes. The drilled hole should be 3mm bigger than the bolt. Use a Bitumen washer to seal holes
8. The hole should be drilled at least 2.95 mm away from the edge of the sheet. Initially tighten nut bolts with the hand only. After 13-14 sheets are installed, only then should all the nut bolts be tightened together
9. Tighten the nut in such a way that the bitumen – washer can seal the space between the bolt and the hole. Do not tighten the bolt too much, otherwise the sheet will crack. Use a spanner to tighten nut finally.
10. For a secure fitting, wherever four sheets have to be joined, the corners should be mitred. The cut corners should be 150 mm in length and 44 mm in breadth. Use a saw to cut corners. Do not use a cutter.
11. Put bolts only in crowns, not in valleys.
12. The bolt should pass through the second and the last sheet.
13. Use a cat ladder for working on the roof.
14. The outlet of the gutter line should not more than 15 meters away.
15. The length of the free overhang should more than 300 mm.



PROCEDURE OF MITRING:

» For the bottom row A, the first sheet should be cut ; DDG.- Cut in the upper left corner.

» For the second and middle rows B cut the bottom right corner of the first sheet.

- » E-upper left-hand corners and bottom right hand corners to be cut.
- » H-cut only upper left corner of the last sheet.
- » For the upper row cut bottom right corners of C, F and F. Fix I without any cut.

